

Coyote popup display set up instructions


Frame Assembly

1



Prepare frame for assembly by locating the purple hooks on top of the frame.

2




Stretch frame to size, snapping magnetic locking arms together.

3



Attach magnetic channel bars to circular magnets.

4



Frame is assembled.

Graphic Application

1



Attach panels starting with left curved endcap panel. Hook panel on purple hooks on front and back of frame. Attach rest of panel to magnetic channel bar.

2



Attach graphic panels from left to right. Hook panels on purple hooks and apply panel to the magnetic channel bar.

3



Continue to attach remaining panels by hooking to purple hooks. Make sure all panel edges align with middle line on channel bars.

4



Graphic application is complete.



watch video