

Wipe Dispenser Wall Mount - HSW-W

For installation onto **PLASTERBOARD/DRYWALL**:

PROFESSIONAL INSTALLATION is recommended

1. Hold the Dispenser Wall Mount in the desired location for mounting along the plasterboard/drywall.
2. With a pencil, mark the locations of both holes onto the plasterboard/drywall.
3. Create clearance holes through plasterboard/drywall using 3/8" drill bit.
4. Mount the Dispenser Wall Mount to the plasterboard/drywall using the provided toggle bolts.

For installation onto **WOOD STUD**:

PROFESSIONAL INSTALLATION is recommended

1. Hold the Dispenser Wall Mount in the desired location for mounting on the wood stud.
2. With a pencil, mark the locations of both holes onto the wood stud.
3. Create pilot holes on the wood using a #48 or 1/16" drill.
4. Mount the Dispenser Wall Mount to the wood stud using the provided wood screws.

