


# 5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT



on frame on graphic



Rope & Stakes w/Bag



Optional Water Base



Crank for peak adjustment



Optional Flag Mount



Optional Sand Bag

## PRODUCT DESCRIPTION

Casita canopies serve as an excellent way to provide shade for outdoor events. The graphic is printed on special water-resistant material and dries immediately during the even more special UV-cured printing process. Finished prints appear shiny and vivid and have added protection against natural elements. This canopy has a 5ft. x 5ft. footprint with five different height settings on the legs. Each square leg is 32mm thick.

DISPLAY DIMENSIONS	59.75" x 59.75" x 103.25"
GRAPHIC DIMENSIONS	46.25"W x 193.5"H (each side)

### GRAPHIC MATERIAL

UV TENT

### GRAPHIC FINISHING

Hemmed around sides and bottom edges.

### DISPLAY CONSTRUCTION

32mm Aluminum Frame

### SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	39 lbs
Shipping Dimensions	50" x 9" x 19"

### LARGE QUANTITY FREIGHT

Freight Shipping	38 boxes per 48" x 40" x 41" skid
Freight Weight	1518 lbs (frame only) 1556 lbs (frame & graphic)

### GRAPHIC TURN AROUND TIME

4 business days after proof approval (up to 2 sets)

### AVAILABLE ACCESSORIES

Rope	Sand Bag
Stakes	La Caja Hard Case
Flag Holder	Travel Bag Wheels

AVAILABILITY	CA Only
WIND RATING	20 mph



Standard Travel Bag



Optional Bag With Wheels



Optional La Caja Hardcase

# 5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT

## PARTS LIST




(qty 1) Canopy Frame



(qty 1) Rope



(qty 1) Travel Bag



(qty 4) Stakes



(qty 1) Bag for Rope & Stakes

# 5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT

## SET UP INSTRUCTIONS

### Step 1

Take your frame and slightly expand it open to expose the corner bars.



### Step 2

Take your canopy graphic and place it on top of the frame.




### Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.



### Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.



### Step 5

Increase the height by extending the lower legs.



### Step 6

Pull each leg down until the latch locks into place.



### Step 7

Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.



### Step 8

The install is complete.

